

**TECHNICAL USER'S MANUAL FOR:**

# **MICROSPACE<sup>®</sup>**

**PC/104 Peripheral boards**

**MSMCAN**

**CAN-BUS interface card**

#260399-1

**DIGITAL-LOGIC<sup>®</sup>**

Nordstrasse 11/F, CH-4542 Luterbach

Tel.: ++41 (0)32 681 53 33 - Fax: ++41 (0)32 681 53 31

**COPYRIGHT © 1992-95 BY DIGITAL-LOGIC AG**

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, in any form or by any means, electronic, mechanical, optical, manual, or otherwise, without the prior written permission of DIGITAL-LOGIC AG.

The software described herein, together with this document, are furnished under a license agreement and may be used or copied only in accordance with the terms of that agreement.

**REVISION HISTORY:**

Prod.-Serialnumber: From:            To:	Product Version	Document Version	Date/Visa:	Modification: Remarks, News, Attention:
		V1.1	02.95 FK	Initial Version
		V1.2	07.95 FK	Current Version
	V1.4B	V1.3	09.96 RP	New Structure
	V1.4B	V1.4	09.96 RP	Jumper
	V1.4B	V1.5	10.96 RP	Function 04, 05, Revision
	V1.4B	V1.51	12.97 SL	Write to register, sample rev.
		V1.52	03.99 TS	Related APP-NOTES
<b>BETA</b>		<b>V1.60b</b>	<b>03.99 JM</b>	<b>Maintenance update</b>

## **Registration Form:**

Please register your product under:

<http://www.digitallogic.ch> -> SUPPORT -> Product Registration

After registration, you will receive driver & software updates, errata information, customer information and news from DIGITAL-LOGIC AG products automatically.

## **Table of Contents**

<b>1</b>	<b>PREFACE.....</b>	<b>6</b>
1.1	How to use this manual.....	6
1.2	Trademarks .....	6
1.3	Disclaimer .....	6
1.4	Who should use this product.....	6
1.5	Recycling information.....	7
1.6	Technical Support .....	7
1.7	Limited Warranty.....	7
<b>2</b>	<b>OVERVIEW .....</b>	<b>8</b>
2.1	Standard Features .....	8
2.2	Ordering Information .....	8
2.3	Related Application Notes.....	8
<b>3</b>	<b>PC/104 BUS SIGNALS.....</b>	<b>9</b>
<b>4</b>	<b>DETAIL SYSTEM DESCRIPTION .....</b>	<b>12</b>
4.1	82527 Controller .....	12
<b>5</b>	<b>DESCRIPTION OF THE CONNECTORS .....</b>	<b>13</b>
5.1	CAN Connector DSUB9.....	13
5.2	J7 Port Expansion P20-P27 for the 82527 Chip .....	13
5.3	J40 PC/104 BUS Interface .....	14
<b>6</b>	<b>JUMPER LOCATIONS ON THE BOARD.....</b>	<b>15</b>
6.1	Jumper Descriptions .....	15
6.1.1	<i>IO-mapped or Memory-mapped.....</i>	15
6.1.2	<i>PLD Equations .....</i>	15
6.1.3	<i>S1 IO-BASE-Address Selection Switch .....</i>	15
6.1.4	<i>S2 IRQ Selector Switch .....</i>	16
6.1.5	<i>S3 NODE Selector Switch .....</i>	16
6.2	Board Layout .....	17
<b>7</b>	<b>SOFTWARE .....</b>	<b>18</b>
7.1	Delivered Software .....	18
7.2	Accessing the CAN-Controller 82527 from Intel .....	18
7.2.1	<i>IO-mapped Operation .....</i>	18
7.2.2	<i>MEMORY-mapped Operation.....</i>	19
7.3	Functions of the CAN-Driver .....	19
7.3.1	<i>Function: INIT CAN with AH = 00 .....</i>	19
7.3.2	<i>Function: TRANSMIT CAN MESSAGE with AH = 01 .....</i>	20
7.3.3	<i>Function: READY CAN with AH = 02.....</i>	20
7.3.4	<i>Function: RECEIVE ONE CAN MESSAGE with AH = 03.....</i>	21
7.3.5	<i>Function: CAN_RxDADR with AH = 4 * .....</i>	22
7.3.6	<i>Function: Get_Status Register with AH = 5 .....</i>	22
7.4	Program Example in Pascal.....	24
<b>8</b>	<b>BUILDING A SYSTEM .....</b>	<b>26</b>
8.1	CAN Bus cable and termination .....	26
8.2	To start the CAN card .....	26
8.2.1	<i>Installation of the CAN-Driver CA_I9.COM or CA_I5.COM .....</i>	26
8.3	The CANTEST.EXE Program to monitor the CAN bus.....	27
8.4	Uninstalling the CAN-Driver CA.....COM.....	29

<b>9</b>	<b>DIAGNOSTICS .....</b>	<b>30</b>
9.1	General.....	30
<b>10</b>	<b>FAILURES AND HINTS.....</b>	<b>31</b>
10.1	CAN does not work .....	31
10.2	500 kBit/s Speed Problem.....	31
<b>11</b>	<b>INDEX .....</b>	<b>32</b>

# **1      **PREFACE****

This manual is for integrators and programmers of systems based on the MICROSPACE card family. It contains information on hardware requirements, interconnections, and details of how to program the system. The specifications given in this manual were correct at the time of printing; advances mean that some may have changed in the meantime. If errors are found, please notify DIGITAL-LOGIC AG at the address shown on the title page of this document, and we will correct them as soon as possible.

## **1.1      *How to use this manual***

This manual is written for the original equipment manufacturer (OEM) who plans to build computer systems based on the single board MICROSPACE-PC. It provides instructions for installing and configuring MICROSPACE boards, and describes the system and setup requirements.

## **1.2      *Trademarks***

Chips & Technologies	SuperState R
MICROSPACE, MicroModule	DIGITAL-LOGIC AG
DOS Vx.y, Windows	Microsoft Inc.
PC-AT, PC-XT	IBM
NetWare	Novell Corporation
Ethernet	Xerox Corporation
DR-DOS, PALMDOS	Digital Research Inc. / Novell Inc.
ROM-DOS	Datalight Inc.

## **1.3      *Disclaimer***

DIGITAL-LOGIC AG makes no representations or warranties with respect to the content of this manual and specifically disclaims any implied warranty of merchantability or fitness for any particular purpose. DIGITAL-LOGIC AG shall under no circumstances be liable for incidental or consequential damages or related expenses resulting from the use of this product, even if it has been notified of the possibility of such damage. DIGITAL-LOGIC AG reserves the right to revise this publication from time to time without obligation to notify any person of such revisions. If errors are found, please contact DIGITAL-LOGIC AG at the address listed on the title page of this document.

## **1.4      *Who should use this product***

- Electronic engineers with know-how in PC-technology.
- Without electronic know-how we expect you to have questions. This manual assumes, that you have a general knowledge of PC-electronics.
- Because of the complexity and the variability of PC-technology, we can't give any warranty that the product will work in any particular situation or combination. Our technical support will help you.
- Pay attention to the electrostatic discharges. Use a CMOS protected workplace.
- Power supply OFF when you are working on the board or connecting any cables or devices.

<p><b>This is a high-technology product.</b> <b>You need know-how in electronics and PC-technology to</b> <b>install the system !</b></p>
---

## 1.5      *Recycling information*

- Hardware:**
- **Print:** epoxy with glass fiber  
wires are of tin-plated copper
  - **Components:** ceramics and alloys of gold, silver  
check your local electronic recycling
- Software:** - **no problems:** re-use the diskette after formatting

## 1.6      *Technical Support*

1. Contact your local Digital-Logic Technical Support in your country.
2. Use Internet Support Request form on <http://www.digitallogic.ch> -> support
3. Send a FAX or an E-mail to DIGITAL-LOGIC AG with a description of your problem.

DIGITAL-LOGIC AG  
Dept. Tech. Support  
Nordstr. 4F  
CH-4542 Luterbach (SWITZERLAND)

Fax: ++41-32 681 53 31  
E-Mail: [support@digitallogic.ch](mailto:support@digitallogic.ch)

- ➔ Support requests will only be accepted with detailed informations about the product (BIOS, Board Version) !

## 1.7      *Limited Warranty*

DIGITAL-LOGIC AG warrants the hardware and software products it manufactures and produces to be free from defects in materials and workmanship for one year following the date of shipment from DIGITAL-LOGIC AG, Switzerland. This warranty is limited to the original product purchaser and is not transferable.

During the one year warranty period, DIGITAL-LOGIC AG will repair or replace, at its discretion, any defective product or part at no additional charge, provided that the product is returned, shipping prepaid, to DIGITAL-LOGIC AG. All replaced parts and products become property of DIGITAL-LOGIC AG.

Before returning any product for repair, customers are required to contact the company.

This limited warranty does not extend to any product which has been damaged as a result of accident, misuse, abuse (such as use of incorrect input voltages, wrong cabling, wrong polarity, improper or insufficient ventilation, failure to follow the operating instructions that are provided by DIGITAL-LOGIC AG or other contingencies beyond the control of DIGITAL-LOGIC AG), wrong connection, wrong information or as a result of service or modification by anyone other than DIGITAL-LOGIC AG. Neither, if the user has not enough knowledge of these technologies or has not consulted the product manual or the technical support of DIGITAL-LOGIC AG and therefore the product has been damaged.

Except, as expressly set forth above, no other warranties are expressed or implied, including, but not limited to, any implied warranty of merchantability and fitness for a particular purpose, and DIGITAL-LOGIC AG expressly disclaims all warranties not stated herein. Under no circumstances will DIGITAL-LOGIC AG be liable to the purchaser or any user for any damage, including any incidental or consequential damage, expenses, lost profits, lost savings, or other damages arising out of the use or inability to use the product.

## **2 OVERVIEW**

### **2.1 Standard Features**

<b>Controller:</b>	Intel 82527
<b>Clock:</b>	16MHz
<b>CAN Specification:</b>	V2.0 part B
<b>Frames:</b>	Standard and extended data and remote frames
<b>Identifier:</b>	Standard and extended message identifier
<b>Objects:</b>	14 TX/RX objects and 1 Rx object with programmable mask
<b>Host Interface:</b>	IO-mapped or memory-mapped 1k window C800, CC00, D000, D400, D800, DC00 200h to 3ffh I/O range
<b>CAN Interface:</b>	Standard ISO/DIS 11898      9 pin DSub
<b>Driver Output:</b>	50 mA
<b>CAN Speed:</b>	up to 500 kBaud
<b>Protection:</b>	Thermal shutdown
<b>Power Supply:</b>	5V
<b>Bus:</b>	PC/104      104 stackthrough pins
<b>Size:</b>	96 x 90 mm
<b>Environmental Temperature:</b>	operating: -25°C to + 85°C storage: - 65°C to +125°C

Any information is subject to change without notice.

### **2.2 Ordering Information**

MSMCAN

MICROSPACE® PC/104 CAN Controller

### **2.3 Related Application Notes**

#	Description
19A	For MSMCAN and other CAN-Products
30	CAN Software
72	CAN 82C527 Controller

➔ Application Notes are available at <http://www.digitallogic.ch> ->support, or on any Application CD from DIGITAL-LOGIC.



## **3 PC/104 BUS SIGNALS**

### **AEN, output**

Address Enable is used to degate the microprocessor and other devices from the I/O channel to allow DMA transfers to take place. **low = CPU Cycle , high = DMA Cycle**

### **BALE, output**

Address Latch Enable is provided by the bus controller and is used on the system board to latch valid addresses and memory decodes from the microprocessor. This signal is used so that devices on the bus can latch LA17..23. The SA0..19 address lines latched internally according to this signal. BALE is forced high during DMA cycles.

### **/DACK[0..3, 5..7], output**

DMA Acknowledge 0 to 3 and 5 to 7 are used to acknowledge DMA requests (DRQ0 through DRQ7). They are **active low**. This signal indicates that the DMA operation can begin.

### **DRQ[0..3, 5..7], input**

DMA Requests 0 through 3 and 5 through 7 are asynchronous channel requests used by peripheral devices and the I/O channel microprocessors to gain DMA service (or control of the system). A request is generated by bringing a DRQ line to an active level. A DRQ line must be held high until the corresponding DMA Request Acknowledge (DACK/) line goes active. DRQ0 through DRQ3 will perform 8-Bit DMA transfers; DRQ5-7 are used for 16 accesses.

### **/IOCHCK, input**

IOCHCK/ provides the system board with parity (error) information about memory or devices on the I/O channel. **low = parity error, high = normal operation**

### **IOCHRDY, input**

I/O Channel Ready is pulled low (not ready) by a memory or I/O device to lengthen I/O or memory cycles. Any slow device using this line should drive it low immediately upon detecting its valid address and a Read or Write command. Machine cycles are extended by an integral number of one clock cycle (67 nanoseconds). This signal should be held low for no more than 2.5 microseconds. **low = wait, high = normal operation**

### **/IOCS16, input**

I/O 16 Bit Chip Select signals the system board that the present data transfer is a 16-Bit, 1 wait-state, I/O cycle. It is derived from an address decode. /IOCS16 is **active low** and should be driven with an open collector (300 ohm pull-up) or tri-state driver capable of sinking 20mA. The signal is driven based only on SA15-SAO (not /IOR or /IOW) when AEN is not asserted. In the 8 Bit I/O transfer, the default transfers a 4 wait-state cycle.

### **/IOR, input/output**

I/O Read instructs an I/O device to drive its data onto the data bus. It may be driven by the system microprocessor or DMA controller, or by a microprocessor or DMA controller resident on the I/O channel. This signal is **active low**.

### **/IOW, input/output**

I/O Write instructs an I/O device to read the data on the data bus. It may be driven by any microprocessor or DMA controller in the system. This signal is **active low**.

**IRQ[ 3 - 7, 9 - 12, 14, 15], input**

These signals are used to tell the microprocessor that an I/O device needs attention. An interrupt request is generated when an IRQ line is **raised from low to high**. The line must be held high until the microprocessor acknowledges the interrupt request.

**/Master, input**

This signal is used with a DRQ line to gain control of the system. A processor or DMA controller on the I/O channel may issue a DRQ to a DMA channel in cascade mode and receive a /DACK.

**/MEMCS16, input**

MEMCS16 Chip Select signals the system board if the present data transfer is a 1 wait-state, 16-Bit, memory cycle. It must be derived from the decode of LA17 through LA23. /MEMCS16 should be driven with an open collector (300 ohm pull-up) or tri-state driver capable of sinking 20mA.

**/MEMR input/output**

These signals instruct the memory devices to drive data onto the data bus. /MEMR is active on all memory read cycles. /MEMR may be driven by any microprocessor or DMA controller in the system. When a microprocessor on the I/O channel wishes to drive /MEMR, it must have the address lines valid on the bus for one system clock period before driving /MEMR active. These signals are **active low**.

**/MEMW, input/output**

These signals instruct the memory devices to store the data present on the data bus. /MEMW is active in all memory read cycles. /MEMW may be driven by any microprocessor or DMA controller in the system. When a microprocessor on the I/O channel wishes to drive /MEMW, it must have the address lines valid on the bus for one system clock period before driving /MEMW active. Both signals are **active low**.

**OSC, output**

Oscillator (OSC) is a high-speed clock with a 70 nanosecond period (14.31818 MHz). This signal is not synchronous with the system clock. It has a 50% duty cycle. OSC starts 100µs after reset is inactive.

**RESETDRV, output**

Reset Drive is used to reset or initiate system logic at power-up time or during a low line-voltage outage. This signal is active high. When the signal is active all adapters should turn off or tri-state all drivers connected to the I/O channel. This signal is driven by the permanent Master.

**/REFRESH, input/output**

These signals are used to indicate a refresh cycle and can be driven by a microprocessor on the I/O channel. These signals are **active low**.

**SAO-SA19, LA17 - LA23 input/output**

Address bits 0 through 19 are used to address memory and I/O devices within the system. These 20 address lines, allow access of up to 1 MBytes of memory. SAO through SA19 are gated on the system bus when BALE is high and are latched on the falling edge of BALE. LA17 to LA23 are not latched and addresses the full 16 Mbytes range. These signals are generated by the microprocessors or DMA controllers. They may also be driven by other microprocessor or DMA controllers that reside on the I/O channel. The SA17-SA23 are always LA17-LA23 address timings for use with the MSCS 16 signal. This is advanced AT96 design. The timing is selectable with jumpers LAXx or SAXx.

**/SBHE, input/output**

Bus High Enable (system) indicates a transfer of data on the upper byte of the data bus, XD8 through XD15. Sixteen-Bit devices use /SBHE to condition data-bus buffers tied to XD8 through XD15.

**SD[O..15], input/output**

These signals provide bus bits 0 through 15 for the microprocessor, memory, and I/O devices. DO is the least-significant Bit and D15 is the most significant Bit. All 8-Bit devices on the I/O channel should use DO through D7 for communications to the microprocessor. The 16-Bit devices will use DO through D15. To support 8-Bit device, the data on D8 through D15 will be gated to DO through D7 during 8-Bit transfers to these devices; 16-Bit microprocessor transfers to 8-Bit devices will be converted to two 8-Bit transfers.

#### **/SMEMR input/output**

These signals instruct the memory devices to drive data onto the data bus for the first MByte. /SMEMR is active on all memory read cycles. /SMEMR may be driven by any microprocessor or DMA controller in the system. When a microprocessor on the I/O channel wishes to drive /SMEMR, it must have the address lines valid on the bus for one system clock period before driving /SMEMR active. The signal is **active low**.

#### **/SMEMW, input/output**

These signals instruct the memory devices to store the data present on the data bus for the first MByte. /SMEMW is active in all memory read cycles. /SMEMW may be driven by any microprocessor or DMA controller in the system. When a microprocessor on the I/O channel wishes to drive /SMEMW, it must have the address lines valid on the bus for one system clock period before driving /SMEMW active. Both signals are **active low**.

#### **SYSCCLK, output**

This is a 8 MHz system clock. It is a synchronous microprocessor cycle clock with a cycle time of 167 nanoseconds. The clock has a 66% duty cycle. This signal should only be used for synchronization.

#### **TC output**

Terminal Count provides a pulse when the terminal count for any DMA channel is reached. The TC completes a DMA-Transfer. This signal is expected by the on-board floppy disk controller. Do not use this signal, because it is internally connected to the floppy controller.

#### **/OWS, input**

The Zero Wait State (/OWS) signal tells the microprocessor that it can complete the present bus cycle without inserting any additional wait cycles. In order to run a memory cycle to a 16-Bit device without wait cycles, /OWS is derived from an address decode gated with a Read or Write command. In order to run a memory cycle to an 8-Bit device with a minimum of one-wait states, /OWS should be driven active one system clock after the Read or Write command is active, gated with the address decode for the device. Memory Read and Write commands to an 8-Bit device are active on the falling edge of the system clock. /OWS is **active low** and should be driven with an open collector or tri-state driver capable of sinking 20mA.

#### **12V +/- 5%**

used only for the flatpanel supply and BIAS generation.

#### **GROUND = 0V**

used for the entire system.

#### **VCC, +5V +/- 0.25V**

separate for logic and harddisk/floppy supply.

## **4      **DETAIL SYSTEM DESCRIPTION****

The MICROSPACE® CAN module performs all serial communication functions such as transmission and reception of messages, message filtering, transmit search, and interrupt search with minimal interaction from the host CPU. The MSMCAN supports the standard and the extended message framed in CAN specification 2.0, part B. Due to the backward compatible nature of the MSMCAN module the standard message frames in CAN specification 2.0, part A, are fully met. The MSMCAN provides storage for 15 message objects of 8 byte data length. Each message object can be configured as either transmit or receive except for the last message object.

The MSMCAN uses a physical CAN bus interface for high speed applications up to 500 kBaud. The interface provides transmit capability to the differential bus and differential receive capability from the CAN bus. Different driver software packages are available for the MSMCAN.

### **4.1      *82527 Controller***

The 82527 Controller is implemented in our boards in mode 3!
--

You will need the Intel Manual for the 82527.

Copies of the 82527Manual or other Intel literature may be obtained from:

Intel Corporation  
Literature Sales  
P.O. Box 7641  
Mt. Prospect, IL 60056-7641

or call 1-800-879-4683

Or ask your local Intel dealer.

## **5 DESCRIPTION OF THE CONNECTORS**

### **5.1 CAN Connector DSUB9**

**J1 and J3:**

Pin 2 = CANL - Signal  
Pin 7 = CANH - Signal  
Pin 3 and Pin 6 are Ground.

J1 defines the AS input from the 82C250.

1 - 2 = VCC  
2 - 3 = GND

### **5.2 J7 Port Expansion P20-P27 for the 82527 Chip**

J7	1.	2.	3.	4.	5.	6.	7.	8.	9.	10.
Signal	VCC	P27/ WAH	P26/INT	P25	P24	P23	P22	P21	P20	GND
82527 PIN		10	11	12	13	14	15	16	17	

### 5.3 *J40 PC/104 BUS Interface*

The cross out signals are not connected on this board.

Pin	A:	B:	C:	D:
0			Ground	Ground
1	IOCHCK	Ground	SBHE	MEMCS16
2	SD7	RESET	LA23	IOCS16
3	SD6	+5V	LA22	IRQ10
4	SD5	IRQ9	LA21	IRQ11
5	SD4	NC	LA20	IRQ12
6	SD3	DRQ2	LA19	IRQ15
7	SD2	(-12V)	LA18	IRQ14
8	SD1	NC	LA17	DACK0
9	SD0	+12V	MEMR	DRQ0
10	IOCHRDY	Ground	MEMW	DACK5
11	AEN	SMEMW	SD8	DRQ5
12	SA19	SMEMR	SD9	DACK6
13	SA18	SIOW	SD10	DRQ6
14	SA17	SIOR	SD11	DACK7
15	SA16	DACK3	SD12	DRQ7
16	SA15	DRQ3	SD13	+5 Volt
17	SA14	DACK1	SD14	MASTER
18	SA13	DRQ1	SD15	Ground
19	SA12	REF	Ground	Ground
20	SA11	SYSCLK		
21	SA10	IRQ7		
22	SA9	IRQ6		
23	SA8	IRQ5		
24	SA7	IRQ4		
25	SA6	IRQ3		
26	SA5	DACK2		
27	SA4	TC		
28	SA3	ALE		
29	SA2	+5 Volt		
30	SA1	OSC		
31	SA0	Ground		
32	Ground	Ground		

## 6 JUMPER LOCATIONS ON THE BOARD

### 6.1 Jumper Descriptions

#### 6.1.1 IO-mapped or Memory-mapped

The MSMCAN operates IO-mapped or Memory-mapped, depending on the PLD-Version and the jumper selections. Refer to the following list:

Jumper / PLD-Version:	IO-mapped: *	MEM-mapped:
<b>J10 Switch</b>	<b>1 - 2 (disable the Sax) *</b> 2 - 3 (enable the SA latch)	2 - 3 (enable SA0-SA7) 1 - 2 (disable the SA latch)
<b>J6 Switch</b>	<b>2 - 3 (enable SA latch) *</b>	1 - 2 (disable the SA latch)
<b>U15 PLD Software Device</b>	MSMCANIO.PP2 GAL20V8A	MSMCANME.PP2 GAL20V8A
<b>Marking on the PLD-Device</b>	CAN IO	CAN MEM

\* Default

#### 6.1.2 PLD Equations

Output:	IO-mapped:	MEM-mapped:
CS244 (Node Switch) = CS373 (IO Address Latch for CANC)	$\neg(\neg/AO * A1 * \neg/SELIO * \neg/IO)$ $\neg/AO * \neg/A1 * \neg/SELIO$	$\leq$ GND
CS245 (Databus Select) = DTR245 =	$\neg(\neg/AO * \neg/A1 * \neg/SELIO)$ IOR	SELMEM MEMR
RW (for CANC) = CANCS (for CANC) =	IOW $\neg(\neg/AO * \neg/A1 * \neg/SELIO)$	MEMW SELMEM
PCINT (PC Interrupt) = IORDY (PC Ready Signal) =	CANINT VCC	CANINT VCC

\* = AND

#### 6.1.3 S1 IO-BASE-Address Selection Switch

<b>Standard board *</b> <b>IO-mapped *</b>	Switch S1	Range 000h - 3ffh
<b>Custom board</b> <b>MEM-mapped</b>	Switch S1	Range A0xxx - FFxxxh

Switch S1		1	2	3	4	5	6	7	8
IO Base address: [hex]	MEM Base address: [hex]								
370	DC0xx	off	off	on	on	on	off	on	on
360	D80xx	off	off	off	on	on	off	on	on
350	D40xx	off	off	on	off	on	off	on	on
<b>340 *</b>	D00xx	off	off	off	off	on	off	on	on
320	C80xx	off	off	off	on	off	off	on	on
310	C40xx	off	off	on	off	off	off	on	on

### 6.1.4 S2 IRQ Selector Switch

Interrupt line:	Switch S2			
	1	2	3	4
IRQ3	on	off	off	off
IRQ5	off	on	off	off
<b>IRQ9 *</b>	off	off	on	off
IRQ4	off	off	off	on

### 6.1.5 S3 NODE Selector Switch

(Read IO-Base+2)

S3-1:	DSACK Input	Not used for PC-CPU's. Only for none Intel-CPU's with non-multiplexed BUS
S3-2:	READY Input	is only in MODE 0 / 1 used and not in Mode 3
S3-3 to S3-8:	Node Number	<b>(free for user) for your own application.</b>

Switch S3 : off = signal to GND, on = signal to VCC, off/on. The position can be either off or on. It has no function in our CAN test program.

Signal	SD0 DSACK	SD1 READY	SD2	SD3	SD4	SD5	SD6	SD7
<b>Switch S3</b>	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>
<b>Standard board *</b>	off	off	off/on	off/on	off/on	off/on	off/on	off/on

**Do not change these Jumpers!**

J11	1-2 = Alternative Interrupt	<b>2-3 = Standard Interrupt *</b>
J5	1-2 = Reset from ISA-BUS (external Reset)	<b>2-3 = Reset from Max1232 (internal Reset) *</b>
J4	1-2 = 82C250 RS to VCC	<b>2-3 = 82C250 RS to GND *</b>

\* Default


The 82C527 controller is implemented into our boards in mode 3.

**Do not change these Jumpers!**

Mode	J8	J9
0	2-3	2-3
1	2-3	1-2
2	1-2	2-3
<b>3 *</b>	<b>1-2</b>	<b>1-2</b>



## 6.2 Board Layout



DIGITAL-LOGIC AG  
4515-OBBERDORF  
PC/104 PRINT SIZE

VERSION: V1.4B  
DATE: 16.Mai 1996  
PRODUCT: MSMCAN

V1.4 modifications  
R41-R48 new  
SWP,PLCC with new PIDs  
Tantal C with new PIDs

## 7 SOFTWARE

### 7.1 Delivered Software

Available from our BBS No. ++41 32 681 53 34 (tools / can.zip).

CA_I5	ASM	35,341	08-31-96	12:43p
CA_I9	ASM	35,341	08-31-96	12:43p
CANTEST	ASM	15,688	08-31-96	4:24p
CANTEST	EXE	3,756	08-31-96	4:24p
DOSLIB	INC	37,006	08-31-96	3:18p
CA_I5	COM	15,323	08-31-96	12:43p
CA_I9	COM	15,323	08-31-96	12:43p
CANSELE	ASM	14,411	08-31-96	3:06p
CANSELE	EXE	3,654	08-31-96	3:05p
MAKECAN	BAT	9	02-07-95	3:12p

### 7.2 Accessing the CAN-Controller 82527 from Intel

#### 7.2.1 IO-mapped Operation

This mode is default on standard boards.

Assumes that the BASE-IO-ADR is selected on 340h:

Assumes that you are using an IO-mapped board with the CANIO PLD.

**Sample:** Read, modify, write-back register 08 of the 82527

Register-Address Register 08	mov mov out	dx, 341h al, 08h dx, al
Register-Address Read register 08 from 82527 to "al"	mov in	dx, 340h al, dx
Modify "register 08" which is in "al" Write modified register 08 back to 82527	or/and out	al, xx dx, al

For testing the correct settings read the power-on default in the Register 02:

Register-Address Register 02	mov mov out	dx, 341h al, 02h dx, al
Register-Address Read register 02 from 82527 to "al"	mov in	dx, 340h al, dx

The result in the "al"-register must be 61h, this is the default value after power-up!

**For more information see 82527 Serial Communications Controller manual „82527pm.pdf” .**

### **7.2.2 MEMORY-mapped Operation**

This mode is only assigned for customer applications.

Assumes that the BASE-MEM-ADR is selected on D0xxh:

Assumes that you are using a MEMORY-mapped board with the CANMEM PLD.

All Registers of the CAN controller 82C527 are directly available. Pay attention to the timing. For the PC-bus you need the double read mechanism for fast access, as proposed by INTEL. Refer to the INTEL documentation.

## **7.3 Functions of the CAN-Driver**

The CAN-driver CA\_I5.COM , CA\_I9.COM provides six general functions: TRANSMIT, RECEIVE, INIT, READY, RxDADR and Get\_Status.

Before the CAN-driver may be accessed, the driver must be installed.

The CA\_I5.COM , CA\_I9.COM CAN-driver is a stay memory resident program, that may be asked from every application or programming language to communicate with the CAN board.

The CAN-driver will be accessed over the software interrupt 61h. The AH register defines the function which must be executed.

After the hardware reset (or power-up) the CAN controller must be initialised, before any other step is performed.

### **7.3.1 Function: INIT CAN with AH = 00**

Function description:

This function initialises the CAN controller on the board. The transfer speed may be selected depending on the CAN nodes. Remember, all CAN nodes must use the same transfer speed.

Register definition before calling the INT61h:

AH = 00	Function request number
AL = undefined	
BL = transfer speed	BL = 00 for 100 kBit/sec
	BL = 01 for 500 kBit/sec
	BL = 02 for 20 kBit/sec
	BL = 03 for 50 kBit/sec

Register definition after returning from INT61h:

AL = Status of the CAN controller

### **7.3.2 Function: TRANSMIT CAN MESSAGE with AH = 01**

#### Function description:

This function transmits one CAN message to the CAN bus. The length of the datafield must be defined over register CL. Since the INTEL CAN controller allows to communicate with basic and with extended CAN, the message type must be defined by register CH. The CAN message is composed of the ARBITRATION- and the DATA-string.

#### Register definition before calling the INT61h:

AH = 01                                      Function request number  
 AL = 01                                      01 uses the first message buffer of the 82527  
 CL = Data Length code CL = 00 .. 08 (8 databytes are the maximum)  
 CH = CAN message type                CH = 00 : BASIC-CAN  
     CH = 01 : EXTENDED-CAN

ES:SI = Pointer to the first byte of the CAN message.

#### CAN Message:

Byte number:	00	01	02	03	04	05	06	07	08	09	0A	0B
Arbitration:	0	1	2	3								
Databytes:					00	01	02	03	04	05	06	07

The number of the valid databytes is defined by register CL.

BASIC-CAN:                Only the first 11 bits of the arbitration string may be used.  
 EXTENDED-CAN:        All 21 bits of the arbitration string may be used.

#### Register definition after returning from INT61h:

AL = Status of the CAN controller

### **7.3.3 Function: READY CAN with AH = 02**

#### Function description:

This function asks the internal receive buffer, if some CAN messages are available. If yes, the AX register returns the number of available messages.

#### Register definition before calling the INT61h:

AH = 02                                      Function request number  
 AL = undefined

#### Register definition after returning from INT61h:

AX = Number of received CAN messages.

### 7.3.4 Function: RECEIVE ONE CAN MESSAGE with AH = 03

#### Function description:

This function receives one CAN message from the internal buffer, if at least one message was in the buffer. After initialising, the driver receives all incoming CAN messages automatically and stores them in the dynamic buffer. This feature prevents the application program to interrupt real-time if the CAN message was received. The capacity of the internal buffer is enough for memorising 1000 messages.

#### Register definition before calling the INT61h:

AH = 03                      Function request number  
AL = undefined

ES : SI =                      Pointer to the first byte of the CAN message buffer, that may be used as a target to transfer the current message.

#### Register definition after returning from INT61h:

AX =      Number of the CAN message. They are available, after transferring the current message. AX = 000 means, no other messages are available in the internal buffer.

ES:SI = Pointer to the first byte of the CAN message buffer, filled with the current CAN message.

#### CAN Message:

Byte number:	00	01	02	03	04	05	06	07	08	09	0A	0B
Arbitration:	0	1	2	3								
Databytes:					00	01	02	03	04	05	06	07

BASIC-CAN:                      Only the first 11 bits of the arbitration string may be used.  
EXTENDED-CAN:                All 21 bits of the arbitration string may be used.

After returning from this function, the transferred CAN message is available in the buffer pointed by the ES-SI registers.

### **7.3.5 Function: CAN RxDADR with AH = 4 \***

Version: 1.1      30.08.96      Felix      Basic Code

#### Function description:

With this function it is possible to put a mask to the message 15 Mask Register 0C, 0D, 0E and 0F. If this function is not used, the default is „don't care“.

A „0“ value means „don't care“ or accept a „0“ or „1“ for that bit position. A „1“ value means that the incoming bit value „must-match“ exactly the corresponding bit in message 15.

See also Intel Manual 82527.

#### Register definition before calling the INT61h:

AH = 04    Function request

BX = Mask15 ID Register **0C** and Reg **0D**

CX = Mask15 ID Register **0E** and Reg **0F**

#### Register definition after returning from INT 61h:

AX = 00

### **7.3.6 Function: Get Status Register with AH = 5**

Version: 1.1      30.08.96      Felix      Basic Code

#### Function description:

This function receives the status information of the 82527 CAN Controller .

For the description of the status register see chapter 7.3.6.1      Status Register (01H) information of the 82527 CAN Controller.

#### Register definition before calling the INT61h:

AH = 05      Function request

#### Register definition after returning from INT 61h:

AX = Status Register 527

#### **7.3.6.1 Status Register (01H) information of the 82527 CAN Controller**

Byte:	07	06	05	04	03	02	01	00
Info:	BOFF	WARN	WAKE	RXOK	TXOK	LEC2	LEC1	LEC1
Dir:	R	R	R	RW	RW	RW	RW	RW

BOFF:	Bus OFF Status: one: There is an abnormal rate of errors occurrences on the CAN bus. More than 256 errors. zero: The 82527 is not bus off, normal operation.
WARN:	Warning Status: one: There is an abnormal rate of occurrences of errors on the CAN bus. More than 96 errors. zero: The 82527 is not in an abnormal error status.
WAKE:	Wake up Status: This bit is set when the 82527 had been previously set into sleep mode by the CPU. This bit is resetted by reading the status register.
RXOK:	Received Message successfully: one: A message has been received successfully. Must be resetted by the CPU after full transmission. zero: No message was received.
TXOK:	Transmitted Message successfully: one: A message has been transmitted successfully. Must be resetted by the CPU after full transmission. zero: Since this bit was last resetted by the CPU, no message has been successfully transmitted.
LEC 0 - 2	Last Error Code 00 No Error  01 Stuff error, more than 5 bits in a sequence have occurred in a part of a received message where this is not allowed.  02 Form Error  03 Acknowledge Error The message transmitted by this device was not acknowledged by another node.  04 Bit 1 Error During the transmission of a message, the 82527 wanted to send a recessive level, but the monitored CAN bus value was dominant.  05 Bit 0 Error During the transmission of a message, the 82527 wanted to send a dominant level, but the monitored CAN bus value was recessive.  06 CRC Error The CRC checksum was incorrect in the message received.  07 unused

## 7.4 *Program Example in Pascal*

The purpose is to make a program in a higher language which uses the six general functions: TRANSMIT, RECEIVE, INIT, READY, RxDADR and Get\_Status from the CAN-driver CA\_I5.COM , CA\_I9.COM  
 Before the CAN-driver may be accessed, the driver must be installed.  
 The CA\_I5.COM , CA\_I9.COM CAN-driver is a stay memory resident program, that may be asked by every application or programming language to communicate with the CAN board.

First we used the program example INTR from the Pascal 6 help .  
 With this example we established the next two programs.

### The CanTran1.exe program transmits one CAN message to the CAN bus.

```
PROGRAM CanTran1;

USES crt,printer,dos;

CONST
  canmessage : array[1..12] of BYTE =
    (02,02,00,00,01,02,03,04,05,06,07,08);

VAR  Daten      : byte;
     regs       : Registers;

{ ***** }
{ * Main                                           * }
{ ***** }
BEGIN
  TEXTCOLOR(lightgreen);TEXTBACKGROUND(blue);CLRSCR;

  WRITELN;
  { ***** }
  { Function Init CAN with AH=00 }
  { ***** }
  { Init CAN function }
  regs.ah := 0;           { Function request number }
  regs.al := 0;           { none }
  regs.bl := 0;           { transferspeed 100k }
  Intr($61,regs);         { Call DOS , Funktion INT61 }

  { ***** }
  { Function Transmit CAN Message with AH=01 }
  { ***** }
  regs.ah := 1;           { Function request number }
  }
  regs.al := 1;           { uses the first message
buffer 1 of the 82527 }
  regs.cl := 8;           { 00..08 databytes }
  regs.ch := 0;           { BASIC-CAN }
  regs.es := Seg(canmessage); { Pointer to the first
  regs.si := Ofs(canmessage[1]); { byte of the CAN message}
  Intr($61,regs);         { Call DOS , Funktion
INT61 }

  daten := regs.al;       { Get Status of the CAN
controller }
  WRITELN;
  WRITE ('Das CAN Resultat ist: ', Daten );
  READLN;
END.
```



**The CANRES1.EXE. program will receive only one message**

```

PROGRAM CanRes1;

USES crt,printer,dos;

CONST
    canmessage : array[1..12] of BYTE =
    (02,02,00,00,01,02,03,04,05,06,07,08);

VAR  Daten          : byte;
     canreceivemess : array[1..12] of byte;
     regs           : Registers;
     c              : integer ;

{ ***** }
{ * Main                                           * }
{ ***** }

BEGIN
TEXTCOLOR(lightgreen);TEXTBACKGROUND(blue);CLRSCR;
WRITELN;
WRITE ('Eine CAN Message wird erwartet: ');

    { ***** }
    { Function Init CAN with AH=00 }
    { ***** }
    { Init CAN function }
    regs.ah := 0;           { Function request number }
    regs.al := 0;           { none }
    regs.bl := 0;           { transferspeed 100k }
    Intr($61,regs);         { Call DOS , Function INT61 }

    { ***** }
    { Function Ready Can with AH=02 }
    { ***** }
    { Get can status }
    Repeat
        regs.ah := 2;       { Function request number }
        regs.al := 0;       { none }
        Intr($61,regs);     { Call DOS , Function INT61 }
    UNTIL (regs.al > 0);

    { ***** }
    { Function Init CAN with AH=03 }
    { ***** }
    { Receive CAN Message }
    regs.ah := 3;           { Function request
number }
    regs.al := 1;           { use message
buffer 1 }
    regs.es := Seg(canreceivemess); { Pointer to the }
    regs.si := Ofs(canreceivemess[1]); { first byte of the CAN message}
    Intr($61,regs);         { Call DOS, Function
INT61 }

    daten := regs.al;


    WRITELN;
    WRITELN ('Anzahl noch vorhandener Messages: ', Daten );
    FOR c:=1 TO 12 DO
    BEGIN
    WRITE (':',canreceivemess[c]);
    END;
    readln;
END.

```

## 8 BUILDING A SYSTEM

### 8.1 CAN Bus cable and termination

The CAN bus must be terminated on each end of the bus with one 120ohm resistor!



### 8.2 To start the CAN card

The CA\_I5.COM, CA\_I9.COM driver is a stay memory resident program, that may be asked by every application or programming language to communicate with the CAN board. The CAN-driver provides four general functions: TRANSMIT, RECEIVE, INIT and READY. Before the CAN-driver may be accessed, the driver must be installed.

#### 8.2.1 Installation of the CAN-Driver CA\_I9.COM or CA\_I5.COM

CA\_I5.COM                      To use with IRQ5 and IO ADR 340  
 CA\_I9.COM                      To use with IRQ9 and IO ADR 340    default

If you need another IRQ or IO ADR it has to be altered in the CA\_I5.ASM, CA\_I9.ASM .

Description	Input	Screen
The CAN board is at default IRQ 9 and address 340. Do not change anything!		
Execute the file CA_I9.COM. The installation message informs you about the successful installation as a memory resident program.	CA_I9.COM [ENTER]	<pre> ***** "* DIGITAL-LOGIC AG  Switzerland      * " ***** * TSR-CAN-Driver 82527   Ver.:1.10b * " ***** "Parameters:  Speed : var 20k to 500k " "      IRQ   :      9      " "      IO ADR :    340/341h  " "      SW INT :    61h     " "      Product:  MSMCAN   " </pre>
If no ERROR Message appears, the installation was successful.		

### 8.3 The CANTEST.EXE Program to monitor the CAN bus

Start the CANTEST.EXE program after installing the CAN-driver CA\_I9.COM. The menu allows you to transmit and to receive CAN messages.  
To communicate with CAN I/O modules from SELECTRON use CANSELE.EXE.

Description	Input	Screen
<p>Start the CANTEST program after installing the CAN-driver CA_I9.COM. The menu allows you to transmit and to receive CAN messages.</p> <p>Chose the speed you wish with cursor down ↓ and cursor up ↑.</p>	<p>CANTEST.EXE [ENTER]</p> <p>cursor down ↓ cursor up ↑ [ENTER]</p>	<p>Communicator for MSMCAN Modules BASIC-CAN Version 1.10c ----- DIGITAL-LOGIC AG Parameters: defined by CA.COM, var. Speed CA.COM Version 1.10 must be loaded before this program ! Only basic CAN mode: ID28 to ID18 are addresses, others are zero.</p> <p>&gt; 100kBit/s 500kBit/s 20kBit/s 50kBit/s</p>
<p>Now the screen will look like this:</p> <p>Each menu can be selected with cursor down ↓ cursor up ↑ and ENTER. If you are not sure about the Input, press ENTER and the default is automatically chosen.</p>		<p>Communicator for MSMCAN Modules BASIC-CAN Version 1.10c ----- DIGITAL-LOGIC AG Parameters: defined by CA.COM, var. Speed CA.COM. Version 1.10 must be loaded before this program! Only basic CAN mode: ID28 to ID18 are addresses, others are zero.</p> <p>&gt; Define Transmit ADR, LEN Define bitrate and init Define Receive Mask ADR Send a message Receive a message Get 527 Status EXIT</p> <p>Rx-Message: 3B25 In Buffer: 03E0 ID: 00000000 DATA: 0000000000000000 Tx-Message: ID: 10000000 DATA: 3344556677889900</p>
If you have chosen every menu, the screen will look like this:		<p>Communicator for MSMCAN Modules BASIC-CAN Version 1.10c -----</p>

**Use the 82527 Intel Manual. The pages and titles are from this Manual. Refer also to the Manual *Functions of the CAN-Driver* (page 19).**

Page 21 Message Object Structure

**ID28-ID21 Target Addr.Bits : 10**

This is the Arbitration 0

**ID20-ID13: 00**

This is the Arbitration 1

The arbitration 2 and 4 is not used in this program.

For the structure of an arbitration see page 23, Arbitration 0, 1, 2, 3 Registers.

**ID: 10                      00                      0000**

Arbitration 0, Arbitration 1, can be anything

**CAN Message Len [0-8] DLC : 08**

This is the Message Configuration Register (page 24).

**ID28-ID21 Receive Mask Bit: 00    ID20-ID13:00**

**[0=undef / 1 = equality]**

**ID28-ID21 Receive Adr.Bits: 00    ID20-ID13:00**

This is the Message 15 Mask Register (0C-0FH) at page 15.

**Status [BOff/Warn/Wake/RxOK/TxOK/Err2/Err1/Err0]: 35**

When an error occurs, refer to the Status Register (01H) page 10/11. See also the ERROR explanations in this Manual at page 22.

**Attention:**

*There is a mistake in the program. The status register must be deleted after receiving the error message. So the value 35 is wrong .*

**Rx-Message: 3B25**

Counter of the message added on the program cantest.ASM

DIGITAL-LOGIC AG Parameters: defined by CA.COM, var.Speed

CA.COM Version 1.10 must be loaded before this program !

Only basic CAN mode: ID28 to ID18 are addresses, other are zero.

ID28-ID21 Target Adr.Bits : 10    ID20-ID13: 00

CAN Message Len [0-8] DLC : 08

ID28-ID21 Receive Mask Bit: 00    ID20-ID13:00 [0=undef / 1=equality]

ID28-ID21 Receive Adr.Bits: 00    ID20-ID13:00

Status [BOff/Warn/Wake/RxOK/TxOK/Err2/Err1/Err0]: 35

> Define Transmit ADR, LEN  
Define bitrate and init  
Define Receive Mask ADR  
Send a message  
Receive a message  
Get 527 Status  
EXIT

Rx-Message: 3B25 In Buffer: 03E0 ID: 00000000 DATA: 0000000000000000

Tx-Message: ID: 10000000 DATA: 3344556677889900

<p><b>In Buffer: 03E0</b> It is implemented in the ca_i9.com. There are 1024 messages possible to store.</p> <p><b>ID: 00000000</b> Target Address from the RX-message</p> <p><b>DATA: 00 00 00 00 00 00 00 00</b> 0 1 2 3 4 5 6 7 These are the data of the message Object Structure, page 21.</p>		
---	--	--

#### 8.4 Uninstalling the CAN-Driver CA.....COM

Description	Input	Screen
Execute the file CA.....COM. The previous installed CAN-driver will be uninstalled. The displayed message informs you about the successful uninstallation from the memory.	CA_I9.COM [ENTER]	Reinstallation of CAN Driver OK

## **9      **DIAGNOSTICS****

### **9.1      *General***

If you need more information on CAN, contact the CIA CAN Automation International Users and Manufacturers Group. Address:

Weichelgarten 26  
D-91058 Erlangen  
Tel. +49-9131-601091  
FAX +49-9131-601092

Copies of the Intel 82527 Manual or other Intel literature may be obtained from:

Intel Coporation  
Literature Sales  
P.O. Box 7641  
Mt. Prospect, IL 60056-7641

or call 1-800-879-4683

Or ask your local Intel dealer.


## 10 FAILURES AND HINTS

### 10.1 CAN does not work

Check:	It is	It must be
cable		
interrupt		
address		
Does the Software, which you have loded, correspond with IRQ and address?		

### 10.2 500 kBit/s Speed Problem

Fast access: With 500kB/s speed transmission we remarked, that it could be necessary to pull-up the Databus of the 82C527 with 10k resistors. All boards V1.4 and later and some of V1.3 have already integrated pull-ups. Older boards may be updated by DLAG.



# 11 INDEX

## 5

500 kBit/s speed problem ..... 31

## 8

82527 Controller ..... 12

## A

Accessing the CAN-Controller 82527 from Intel..... 18

## B

Board ..... 17  
BOFF ..... 23

## C

CA\_I5.COM ..... 26  
CA\_I9.COM ..... 26  
cable ..... 26  
CAN Connector DSUB9 ..... 13  
CAN Message Len [0-8] DLC : 08 ..... 28  
CANH - Signal ..... 13  
CANL - Signal ..... 13  
CanRes1 ..... 25  
CANTEST.EXE ..... 27  
CanTran1 ..... 24  
CIA Can in Automation International Users and  
Manufacturers Group ..... 30

## D

DATA: 0000000000000000 ..... 28; 29  
Diagnostics ..... 30

## E

ERROR explanations ..... 28

## F

Failure and Hints ..... 31

## G

GAL20V8A ..... 15

## I

ID: 00000000 ..... 28; 29  
ID20-ID13: 00 ..... 28  
ID28-ID21 Target Addr.Bits : 10 ..... 28

In Buffer : 03E0 ..... 28; 29

Intel Coporation ..... 30  
IO-mapped ..... 15  
IO-mapped Operation ..... 18

## J

J113 .....  
J10 Switch ..... 15  
J3: ..... 13  
J6 Switch ..... 15  
J7 Porterweiterung ..... 13  
Jumper descriptions ..... 15

## L

layout ..... 17  
LEC 0 - 2 ..... 23  
Literature Sales ..... 30

## M

Mask Register ..... 28  
memory-mapped ..... 15  
MEMORY-mapped Operation ..... 19  
mode 3! ..... 12  
MSMCANIO.PP2 ..... 15  
MSMCANME.PP2 ..... 15

## O

Ordering information ..... 8

## P

PC/104 BUS Interface ..... 14  
PLD Equations : ..... 15

## R

Receive Mask ..... 28  
RECEIVE ONE CAN MESSAGE ..... 21  
RXOK ..... 23

## S

S1 BASE-Address Selection Switch ..... 15  
S2 IRQ Selector Switch ..... 16  
S3 NODE Selector Switch ..... 16  
signals ..... 9  
software ..... 18  
speed ..... 27  
Standard features ..... 8  
Status ..... 28  
Status Register (01H) information ..... 22

## T

termination ..... 26  
The Functions of the CAN-Driver ..... 19



TXOK..... 23

U

U15 PLD ..... 15  
Uninstalling the CAN-Driver CA.....COM ..... 29

W

WAKE..... 23  
WARN ..... 23